

Firming Décolleté Overnight Mask

Ref: PS3-187

This mask is designed to firm, strengthen and moisturize your most challenging and delicate area. **SLENDYL** combines two brown algae extracts that act through a global strategy based on the three main pathways of fat accumulation: adipogenesis, lipogenesis and lipolysis, with in addition reinforcement of skin firmness. **SLIMAGINE** provides long-lasting slimming benefits.

INCI	Trade Name	Supplier	% W/W
Phase A			
D.I. Water	D.I. Water		Q.S.
Disodium EDTA	Protachem-Na-2P	Protameen	0.10
Methyl Gluceth-20	RITACAM E-20	RITA	3.00
Propylene Glycol	Propylene Glycol		3.00
Carbomer	Carbopol Ultrez 30 Polymer	lubrizol	0.30
Phase B			
Caprylic/Capric Triglyceride	Botanester GC	Botanigenics	5.00
Simmondsia Chinensis (Jojoba) Seed Oil	IntegriLIPID Jojoba Oil	Integrity Incred.	3.00
Isostearyl Neopentanoate	Jeechem ISNP	JEEN	3.00
Squalane	Pripure 3759-LQ-(GD)	Croda	2.00
Glyceryl Stearate (and) PEG-100 Stearate	Botanimulse 165	Botanigenics	3.00
Isopropyl Isostearate	Dermol IPIS	ALZO	3.00
Cetearyl Alcohol (and) Polysorbate 60	Botanimulse P	Botanigenics	2.50
PEG-40 Stearate	Jeemate 2000-DPS flake	JEEN	1.00
Polyglyceryl-3 Beeswax	Cera Bellina	Koster Keunen	1.00
Phase C			
TEA	TEA		0.30
Phenoxyethanol (and) Ethylhexylglycerin	Euxyl PE 9010	Schülke Inc.	1.00
Water (and) Himanthalia Elongata Extract (and) Undaria Pinnatifida Extract	Slendyl	Biosil	3.00
PALMARIA PALMATA EXTRACT	Slimagine	Biosil	2.00
Acrylamide/Sodium Acryloyldimethyl Taurate Copolymer & Isohexadecane & Polysorbate 80	Simulgel 600	Seppic	2.00
Fragrance	Tonique de Citron S8-41311	Premier	0.18

Procedure: Add water to the main beaker. Add ingredients of Phase A one by one with mixing. Heat it to 70C until it is uniform. Combine ingredients of Phase B together. Heat it with mixing until it is clear. Add Phase B into Phase A with mixing. Stop heating. Cool it down to 40C. Add ingredients of Phase C one by one with mixing.

Parameters: Viscosity 85200 CPS, S#6 @5 RPM. pH 5.4.

Stability: Acceptable 8 weeks stability study at 4°C, RT, 45°C, and 3 cycles F/T.

Direction how to use: apply the mask to your fingertips. Using downward movements, gently massage the mask onto cleansed, dry skin of the neck and décolleté. Enjoy a good night sleep.

The information presented herein is offered solely for your consideration and investigation. It is intended for use by persons having technical and formulation expertise, at their own risk. No warranty is expressed or implied. Nothing herein is to be taken as a license to operate under or to encourage the infringement of any patents or any other intellectual property. Biosil assumes no liability in connection with the use of this information. Anyone intending to use this information is responsible for determining whether the information meets all safety, health and regulatory standards appropriate to and applicable for their intended use.