

Wipe Off Lip and Smile Mask

Ref: PS3-177

This mask is designed to make you smile. **Epidermosil** is a silanol with Hyaluronic Acid to stimulate cell renewal. **Biosil EFA** provides essential fatty acids and **PAE Complex Hydration and Repair** will exfoliate, moisturize and soothe allowing the active ingredient, Ocea Care, to penetrate more evenly and deeply to increase its efficacy.

INCI	Trade Name	Supplier	% W/W
Phase A			
D.I.Water	D.I.Water		Q.S.
Disodium EDTA	Protachem-Na-2P	Protameen	0.10
Methyl Gluceth-20	RITACAM E-20	RITA	3.00
Propylene Glycol	Propylene Glycol		3.00
Carbomer	Carbopol Ultrez 30 Polymer	lubrizol	0.30
Phase B			
Caprylic/Capric Triglyceride	Botanester GC	Botanigenics	5.00
Simmondsia Chinensis (Jojoba) Seed Oil	IntegriLIPID Jojoba Oil	Integrity Ingred.	3.00
Isostearyl Neopentanoate	Jeechem ISNP	JEEN	3.00
Squalane	Botanessential Olivane	Botanigenics	2.00
Glyceryl Stearate (and) PEG-100 Stearate	Botanimulse 165	Botanigenics	3.00
Isopropyl Isostearate	Dermol IPIS	ALZO	3.00
Cetearyl Alcohol (and) Polysorbate 60	Botanimulse P	Botanigenics	2.50
PEG-40 Stearate	Jeemate 2000-DPS flake	JEEN	1.00
Polyglyceryl-3 Beeswax	Cera Bellina	Koster Keunen	1.00
Phase C			
TEA	TEA		0.30
Phenoxyethanol (and) Ethylhexylglycerin	Euxyl PE 9010	Schülke Inc.	1.00
Sodium hyaluronate (and) silanetriol (and) water	Epidermosil	Biosil	6.00
Linoleic Acid (and) Linolenic Acid (and) Tocopherol	Biosil EFA	Biosil	1.00
Aloe Barbadosensis Leaf Juice (and) Glycerin (and) Phytic Acid (and) Laminaria Saccharina Extract	PAE Complex Hydration and Repair	Biosil	5.00
Acrylamide/Sodium Acryloyldimethyl Taurate Copolymer & Isohexadecane & Polysorbate 80	Simulgel 600	Seppic	2.00
Red#33	1% solution		0.016
Fragrance	Creamy Strawberry flavor EE18-28404 Fp: 144F	Premier	0.50

The information presented herein is offered solely for your consideration and investigation. It is intended for use by persons having technical and formulation expertise, at their own risk. No warranty is expressed or implied. Nothing herein is to be taken as a license to operate under or to encourage the infringement of any patents or any other intellectual property. Biosil assumes no liability in connection with the use of this information. Anyone intending to use this information is responsible for determining whether the information meets all safety, health and regulatory standards appropriate to and applicable for their intended use.



T 201-825-8800 | F 201-825-8810
6A Pearl Court, Allendale, NJ 07401
www.biosiltech.com

Procedure: Add water to the main beaker. Add ingredients of Phase A one by one with mixing. Heat it to 70C until it is uniform. Combine ingredients of Phase B together. Heat it with mixing until it is clear. Add Phase B into Phase A with mixing. Stop heating. Cool it down to 40C. Add ingredients of Phase C one by one with mixing.

Parameters: Viscosity 85200 CPS, S#6 @5 RPM. pH 5.4.

Stability: Acceptable 8 weeks stability study at 4°C, RT, 45°C, and 3 cycles F/T.

Direction how to use: apply the mask to cleansed lips and around the mouth using your fingertips with an even and generous layer. Leave on 5-15 minutes. Gently tissue off excess and massage residual into skin.

The information presented herein is offered solely for your consideration and investigation. It is intended for use by persons having technical and formulation expertise, at their own risk. No warranty is expressed or implied. Nothing herein is to be taken as a license to operate under or to encourage the infringement of any patents or any other intellectual property. Biosil assumes no liability in connection with the use of this information. Anyone intending to use this information is responsible for determining whether the information meets all safety, health and regulatory standards appropriate to and applicable for their intended use.